

Warning Symbols Quick Reference Guide



HEST

Hot Exhaust
Keep vehicle a safe distance from combustibile items



CHECK ENGINE

Engine



MIL

Engine - Emissions



EMISSIONS SYSTEM

Emissions Related Engine Derate

- **Perform stationary regeneration**
- **Add DEF fluid** (more than 1/4 tank)
- **Seek service at the next stop if the warning light is still on**



COOLANT TEMP

Stop vehicle and idle engine



DPF

Diesel Particulate Filter
Perform regeneration



DEF

Diesel Exhaust Fluid
Fill DEF tank if gauge reads low level. Otherwise seek service immediately for DEF fluid quality or DEF equipment repair



ENGINE OIL PRESSURE

Stop the engine or the engine may automatically shutdown.



STOP ENGINE

(May not apply for fire or emergency vehicle applications)

Any of the above icons may appear alone or together to alert of necessary action to be taken as soon as possible.

These lights will start flashing to notify of the upcoming engine derate.

Refer to the *Engine Aftertreatment Controls* manual for more details.